



# Burst generator 125 kHz

# **SFT 1400**



- Frequency up to 125 kHz
- Changing of all parameters during a burst test
- IEC 61000-4-4, July 2005, incl. IEC Corrigendum 2, June 2007 a. Ed.3, 2011
- Single spike to continuous burst
- 5000 pulses/sec 500/package
- Various special function

#### Introduction

The test generator simulates quick transient noise interference as they are defined in the standards IEC 61000-4-4 and EN 61000-4-4. The single pulses show a very short rise-time (5ns) and due to this a wide RF-spectrum up to 300 MHz. RF-interferences are the result.

# **Special function**

The generator includes several special functions such as "Real Burst" which simulates the natural appearance of the burst phenomena or "Sweep" to simulate the bouncing of an electrical contact. The functions "IFM" and "DFM" (increasing and decreasing frequency) are powerful instruments to investigate resonance or saturation effects in the tested device.


# Easy operation

The clearly arranged front panel with the generator settings allows a time-saving and optimised testing. The standard test level 1, 2, 3 and 4 are stored in the memory function on position 1 - 4. Additional custom made setups can be stored in the memory function.

# Burst definition (see drawing 1)

designation	param.	standard definition	variable setup on SFT 1400
burst duration	а	15 ms $\pm$ 20% at 5 kHz 0,75 ms $\pm$ 20% at 100 kHz (correspond to 75 pulses /package)	0,01 - 100 ms * <sup>1</sup>
burst period	b	300 ms $\pm$ 20 %	10 - 1000 ms * <sup>1</sup>
burst frequency	С	5 kHz or 100 kHz up to 4 kV	100 Hz - 125 kHz up to 5 kV
pulse amplitude	U	0,5 / 1 / 2 / 4 kV	200 V - 5000 V (into 10 V steps)
pulse rise-time	t <sub>r</sub>	5 ns $\pm$ 30 %	
pulse width (50 Ohm) pulse-width (1 kOhm)	t <sub>w</sub>	50 ns ± 30 % 50 ns, -15ns/+100 ns	*1: the SFT 1400 automatically concerns the units. maximum power restrictions
impedance	Z	50 $\Omega$ $\pm$ 2 %	

11207



3

- [1] Earth connection
- [2] Laboratory jacks for EUT connection.
- [3] Protected earth outlet for EUT connection.
- [4] Polarity of the burst packet.
- [5] Trigger release key, external trigger input.
- [6] Selection key for the period-time.
- [7] Selection key for the test-time.
- [8] Digital potentiometer.
- [9] Selection of the special functions.
- [10] Jack for interface cable.
- [11] Remote control release.
- [12] Activation of the memory function.
- [13] Selection key for the duration-time.
- [14] Selection key for the frequency.
- [15] Indicator for surge active.
- [16] Displays for the memory mode.
- [17] Display for the pulse-voltage.
- [18] Coupling selection for the paths L, N and PE.
- [19] Phase indicators.
- [20] Monitoring (TTL output)
- [21] HV-output for the connection of a capacitive coupling clamp or 3-phase coupling network

#### **Technical data**

•	Burst frequency	single up to 125 kHz
•	Pulse amplitude	200 V - 5000 V
•	Polarity burst package	pos., neg., alternating
•	Pulse shape	accord. to IEC 61000-4-4
•	Max. Pulses / sec	5000 (up to 2 kV);

3000 (up to 3 kV) and

1500 (up to 5 kV)
Max. Pulses / package 500

♦ Remote control RS 232

(6)

5

## Coupling network

 Integrated in the test generator, coupling of the noise pulses to the EUT's power mains

(8)

Nominal voltage max. 250V / 16A, 50 Hz
 Voltage DC max. 110V / 8A
 Phase indicator lamp red / green

♦ Coupling capacity 33 nF

Coupling selectors L, N, PE ->E; L, N->E; a.s.o.
 EUT power outlets protection earth outlet additional lab. terminals

Pulse output FISCHER coax HV-jack

# Common

◆ Operation temp. 0 - 40 °C
 ◆ Dimensions 19" housing. 3 HE

♦ Weight 10 kg

♦ Power supply 230V / 100VA, 50 Hz

## **Options**

3-phase coupling
3-phase coupling
3-phase coupling
3-phase coupling
CWG 520 (4x16 A)
CWG 523 (4x32 A)
CWG 524 (4x60 A)

Coupling clamp SFT 415
Attenuator SFT 450
100:1/50 Ohm

◆ Probe set SFT 470◆ Control software EMV-SOFT

Schlöder GmbH

★ +49-7236/9396-0 • ♣ +49-07236/9396-90 eMail: info@schloeder-emv.de Internet: www.schloeder-emv.de